



## VHS transfer to DVD

First turn on the VHS/DVD Player and the Monitor above the unit. **DVD-R** or **DVD-RW** are the only burn compatible disk formats.

Note: You must use the remote control for the following:

### Preparing for dubbing (cassette tape to DVD):

- Insert a cassette tape to be dubbed.
- Insert a recordable DVD.
- Make sure there is enough space on the DVD.



**1** Press [SETUP] and use [▲ / ▼] to select "General Setting", then press [OK].

"General Setting" menu will appear.


**2** Use [▲ / ▼] to select "Recording", then press [OK].

"Recording" menu will appear.

**3** Use [▲ / ▼] to select "Dubbing Mode", then press [OK].

Selection menu will appear.

**4** Use [**▲** / **▼**] to select “VCR → DVD”, then press [OK].



Press [SETUP] to exit.

---

**5** Press [DVD], then press [REC MODE] repeatedly to select the desired recording mode.

---

**6** Press [VCR], then press [**▶**] to find the point where you wish to start dubbing.

---

**7** Press [**||**] when you come to the desired start point.

---

**8** Press [D.DUBBING].  
VCR to DVD duplication will start.

---

**9** Press [**■**] to stop the dubbing.

# Important:

## PLAYING THE DISCS ON OTHER DVD PLAYERS


### Finalizing a Disc



You will need to finalize DVD-RW or DVD-R to play them back on other DVD players.


Finalizing may take several minutes up to an hour.

A shorter recording period on the disc will require a longer time period for finalization. Do not unplug the power cord during finalization.



#### Note

- Once you have finalized a DVD-R, you cannot edit or record anything on that disc.
- Even if you have finalized a DVD-RW recorded in VR mode, you can edit, record or delete a title.
- When you insert a DVD-RW finalized with this unit, "Undo Finalize" will appear instead of "Finalize".



To release the finalizing for the disc, select "Undo Finalize" at step 3.


\* DO NOT turn the power off or to the standby mode during finalization, this will result in malfunction.

**1** Press [SETUP].


**2** Use [▲ / ▼] to select "DVD Menu", then press [OK].  
"DVD Menu" menu will appear.

**3** Use [▲ / ▼] to select "Finalize", then press [OK].

**4** Use [▲ / ▼] to select "Yes", then press [OK].




Finalizing will start.



#### To cancel finalizing...

(DVD-RW only)

- To cancel finalizing at step 4, press [■], select "Yes" with [▲ / ▼], then press [OK]. Finalizing is cancelled and the unit will be in stop mode.



- If [⏸] appears when pressing [■], you cannot cancel finalizing because the finalizing has been in progress.
- When selecting "No" and press [OK] or [RETURN], finalizing will be continued.
- You cannot cancel finalizing the DVD-R once it has started.

This operation may take a while to be completed.

**5** Finalizing is completed.